

常設用

名称	メーカー	型番	仕様	数量
main mixer	YAMAHA	M7CL-32	32in 4STin,16OMN1out	1
proscenium SP	ELECTROVOICE	TL606DX		1/ch
	ELECTROVOICE	DH1A		2/ch
side SP	ELECTROVOICE	DML1122A		1/ch
proscenium AMP	ACCUPHASE	PRO6		2
	ACCUPHASE	PRO10		1
side AMP	ACCUPHASE	PRO6		1
	ACCUPHASE	PRO10		1
moni AMP	ACCUPHASE	PRO2		3
moni SP	ELECTROVOICE	S-200		6
	YAMAHA	4115A		2
MIC	ZENHEIZER	421		4
	SONY	C536P		3
	SANKEN	CU-31		3
	AKG	C451		2
	SHURE	SM-58		9
	SHURE	SM-57		2
	SHURE	565SD		2
WL MIC	SHURE	ULXD1	PIN type	4
	SHURE	ULXD2	BETA58A head	8
mic stand			boom	16
			short boom	6
			floor	6
			table	6
カセットレコーダ	SONY	K555ESJ		1
MDレコーダ	TASCAM	MD-350		1
CDプレーヤー	TASCAM	CD-500B		2
CD,USB,SD,CFレコーダー	TASCAM	SS-CDR200		1

仮設用

名称	メーカー	型番	仕様	数量
mixer	mackie	CR-1604VLZ	16in 4group+LR+6AUXout	1
mixer	YAMAHA	01	16in デジタルミキサー	1
GEQ	BEHRINGER	DSP-8000		2
COMP	dbx	166A		2
REV	YAMAHA	REV500		1
AMP	YAMAHA	HC-2700		3
SP	BOSE	802 II		4
	BOSE	502BP		2
SP STAND	BOSE	SS-5 II		2
MULITI REEL	CANARE	16RJ30-E3	16CHパラ 30m	

小浜市文化会館 音響機材リスト